



HULL GUARD PENDANT LANTERN INSTALLATION GUIDE

Product codes: 09130, 09141, 09135

INSTRUCTIONS FOR USE AND INSTALLATION

GENERAL INFORMATION & TECHNICAL SPECIFICATIONS

PRODUCTS MANUFACTURED IN EU

- 230V ~ 50Hz
 - Class I
 - E27 porcelain lamp holder
 - Not intended for mesh connection.
 - Intended for connection to fixed wiring.
 - 3G1.5 power cable should be used for the connection of the light fixture.
 - External power cable not included.
-

GENERAL INFORMATION ABOUT SAFETY

- Before any work, turn off the mains supply.
- Installation should only be carried out by a qualified electrician, who should be aware of the current Regulations on Internal & External Installations.
- In case of glass breakage, replace immediately.
- Lightbulb Wattage should never exceed the Wattage (W) indicated on the label or packaging of the light fixture.

Address: Navigator Lighting (part of Lampfix) Unit 6 Fen End, Stotfold, Hitchin, Herts. SG5 4BA

Tel: 01462 731173 | Email: sales@navigatorlighting.co.uk | Website: navigatorlighting.co.uk

V1 20.10.2025



- The fitting should be connected to a line protected by a differential current circuit, while the nominal persistent operating current should not exceed 30mA (leakage relay).
-

Included in the package:

1 light fixture

1 tripolar sealed junction box

LIGHT FIXTURE INSTALLATION

A. MOUNTING THE LIGHT FIXTURE AND CONNECTING THE POWER CABLE

- Mark the surface on which the light fixture will be fixed.
 - Drill holes on mounting surface and insert the wall plugs.
 - Screw the hook onto the back plate.
 - Hang the light fixture from the hook and adjust the desired length of the chain. Pass the power cable through the chain.
 - Cover the wires with supplied insulating hoses.
Connect the main cable and the light fixture cable wires to the terminal block in the junction box, using the L (Line: Brown wire), N (Neutral: Blue wire) & \equiv (Grounding: yellow/green wire) symbols.
 - Raise the ceiling loop that bears the cables and the ring and screw them in place.
 - Unscrew the cage and remove the glass from the body of the light fixture.
 - Fit the light bulb into the lamp holder.
 - Screw the cage and the glass to the body of the light fixture.
 - Feed the light fixture.
-

B. REPLACING THE LIGHTBULB

Address: Navigator Lighting (part of Lampfix) Unit 6 Fen End, Stotfold, Hitchin, Herts. SG5 4BA

Tel: 01462 731173 | Email: sales@navigatorlighting.co.uk | Website: navigatorlighting.co.uk

V1 20.10.2025



Navigator

- Turn off the mains supply.
- Do not change the lightbulb unless it has completely cooled down as it may cause serious burns on the skin.
- Open the lightbulb cover.
- Twist and pull the bulb gently.
- Always use clean protective gloves when handling a lightbulb.
- Avoid using damp cloth when replacing the lightbulb to avoid accidental breakage.
- Never clean or wash the lightbulb.
- Replace the lightbulb's cover to maintain the impermeability of the fixture.

The manufacturer bears no responsibility for any injury or damage resulting from incorrect installation or use of the product.

Address: Navigator Lighting (part of Lampfix) Unit 6 Fen End, Stotfold, Hitchin, Herts. SG5 4BA

Tel: 01462 731173 | Email: sales@navigatorlighting.co.uk | Website: navigatorlighting.co.uk

V1 20.10.2025