Grand Capstan Bulkhead Installation Guide

Product codes: 09079, 09613, 09311

INSTRUCTIONS FOR USE AND INSTALLATION

GENERAL INFORMATION & TECHNICAL SPECIFICATIONS

PRODUCTS MANUFACTURED IN EU

- 230V ~ 50Hz
- Class I
- E27 porcelain lamp holder
- Not intended for mesh connection.
- Intended for connection to fixed wiring.
- Double-insulation 3G1.5 power cable should be used for the connection of the light fixture.
- Power cable not included.

GENERAL INFORMATION ABOUT SAFETY

- Before any work turn off the mains supply.
- Installation should only be carried out by a qualified electrician, who should be aware of the current Regulations on Internal & External Installations.
- In case of glass breakage, replace immediately.
- Lightbulb Wattage should never exceed the Wattage (W) indicated on the label or the packaging of the light fixture.
- The product should be connected to a line protected by a differential current circuit, while the nominal persistent operating current should not exceed 30mA (leakage relay).

Included in the package:
1 Light fixture

1 plastic insulating cover for the lamp holder
2 sets of wall-plugs and screws
2 rubber retainers
2 plastic washers
3 insulating hoses

LIGHT FIXTURE INSTALLATION

A. FIXING THE LIGHT FIXTURE ON A MOUNTING SURFACE

- Unscrew the cage and remove the glass from the body of the light fixture.
- Using the body of the light fixture as an installation guide, mark the surface on which you wish to mount it.
- Drill holes on the mounting surface and fasten the body of the light fixture to it, using the supplied wall-plugs and screws. To ensure the insulation of the light fixture, use the plastic washers and rubber retainers when screwing the screws.

B. CONNECTING THE POWER CABLE

- Pass the cable through the cable clamp.
- Cover the wires with the supplied insulating hoses.
- Connect the line (brown) and neutral (blue) wires to the lamp holder and the grounding wire (yellow) to the body of the light fixture next to the grounding symbol ⏚, using the supplied screw and M4 washer.
- Place the plastic insulating cover under the lamp holder.
- Screw the lamp to the lamp holder.
- Fit the glass and fasten the cage to the body of the light fixture.
- Turn on the power supply.

C. REPLACING THE LIGHTBULB

- Turn off the mains supply.
- Do not try to replace the lightbulb unless it has completely cooled down as it may cause serious burns on the skin.
- Open the lightbulb's cover.
- Twist and pull the lightbulb gently.
- Do not touch the lightbulb with bare hands.
- Always use clean protective gloves when handling a lightbulb.
- Use a clean towel to clean the lightbulb in case you touch it accidentally.

- When replacing the lightbulb, twist it very carefully while it is still in the lamp holder.
- Before feeding again with power, replace the lightbulb's cover to maintain the impermeability of the fixture.

The manufacturer bears no responsibility for any injury or damage resulting from incorrect installation or use of the product