



Tiller Wall Lantern Installation Guide

Product codes: 09138, 09137, 05961

INSTRUCTIONS FOR USE AND INSTALLATION

GENERAL INFORMATION & TECHNICAL SPECIFICATIONS

PRODUCTS MANUFACTURED IN EU

- 230V ~ 50Hz
- Class I
- Not intended for mesh connection.
- Intended for connection to fixed wiring.
- Double-insulation 3G1.5 power cable should be used for the connection of the light fixture.

GENERAL INFORMATION ABOUT SAFETY

- Before any work turn off the mains supply.
- Installation should only be carried out by a qualified electrician, who should be aware of the current Regulations on Internal & External Installations.
- In case of glass breakage, replace immediately.
- Lightbulb Wattage should never exceed the Wattage (W) indicated on the label or the packaging of the light fixture.
- The product should be connected to a line protected by a differential current circuit, while the nominal persistent operating current should not exceed 30mA (leakage relay).

Included in the package:

- 1 Light fixture – wall sconce
- 1 plastic back plate
- 2 sets of wall-plugs and screws
- 2 stainless steel hex head M5 screws
- 2 M5 screw caps (blind nuts)

Address: Navigator Lighting (part of Lampfix) Unit 6 Fen End, Stotfold, Hitchin, Herts. SG5 4BA



- 1 terminal block
- 1 rubber inlet for the power cable

LIGHT FIXTURE INSTALLATION

A. MOUNTING THE LIGHT FIXTURE AND CONNECTING THE POWER CABLE

- Mark the surface on which the light fixture will be fixed, using the back plate as a guide.
- Drill holes on the mounting surface and insert the wall-plugs.
- Insert the stainless steel hex head M5 screws into the back plate.
- Pass the supply cable through the back plate using the supplied rubber inlet.
- Screw the back plate on the mounting surface with the supplied screws.
- Attach the terminal block to the back plate.
- Connect the power cable and the light fixture cable wires to the terminal block, using the L (Line: Brown wire), N (Neutral: Blue wire) & $\frac{1}{\text{---}}$ (Grounding: Yellow wire) symbols as reference.
- Place the fixture on the back plate and fasten it, screwing the M5 brass blind nuts by hand onto the stainless M5 hex head screws. Fasten them in place, using a wrench. 1 full 360° revolution of the wrench is enough.
- Unscrew the cage and remove the glass of the light fixture.
- Screw the lightbulb into the lamp holder.
- Replace the glass and screw the cage and screw the cage on the body of the light fixture.
- Feed the light fixture.

B. REPLACING THE LIGHTBULB

- Turn off the mains supply.
- Do not try to replace the lightbulb unless it has completely cooled down as it may cause serious burns on the skin.
- Open the lightbulb's cover.
- Twist and pull the lightbulb gently.
- Do not touch the lightbulb with bare hands.
- Always use clean protective gloves when handling a lightbulb.
- Use a clean towel to clean the lightbulb in case you touch it accidentally.
- When replacing the lightbulb, twist it very carefully when the lightbulb is still in the lamp holder.

Address: Navigator Lighting (part of Lampfix) Unit 6 Fen End, Stotfold, Hitchin, Herts. SG5 4BA



- Before feeding again with electrical power, replace the lightbulb's cover to maintain the impermeability of the fixture.

The manufacturer bears no responsibility for any injury or damage resulting from incorrect installation or use of the product

Address: Navigator Lighting (part of Lampfix) Unit 6 Fen End, Stotfold, Hitchin, Herts. SG5 4BA

Tel: 01462 731173 | Email: sales@navigatorlighting.co.uk | Website: navigatorlighting.co.uk V1 20.10.2025